



Setting speed dials on a Samsung phone:

1. Enter the Programming Mode

TO ENTER THE PROGRAMMING MODE

Press **TRSF** then **200**

Dial the 4-digit passcode **1972**

Press 1 to enable programming

2. Press **TRSF** then **705** (Display shows first speed dial 500)
3. Dial the desired speed number i.e. 500 - 699
4. Dial your outside line access number eg. 9
5. Dial the telephone number you wish to store; if you make a mistake, press **HOLD**
6. Press the right soft key to return to step 3 if you wish to add more Entries
7. Press **TRFS** to Store

SYSTEM SPEED DIAL NAMES

1. Enter the Programming Mode
2. Press **TRSF** then **706**
3. Dial the Speed Code number i.e. 500
4. Enter the name from the alphabet on your numerical keypad
5. Press the right soft key to return to step 3 if you wish to continue
6. Press **TRFS** to Store

If you wish to have the programmed name shown while receiving a call

1. Press **REDIAL** whilst entering speed dials and you will see the Option **ADD CLI XLT**
2. Dial 1 to add the name to the calling line identity list.